

UNLATCHING PROCEDURE FOR ALL SAMSUNG DEVICES:

Note: If the unlocking code is entered incorrectly 3 times the device will be locked.

1. Insert a non O2 **active** sim card in the device.
2. This should ask for a code.
3. Input 8 digits unlock code when requested.
4. Device will be unlocked.